

Set Up Steps

1. Unpack parts. (Large and small shown)



2. Open the 2 valves/stoppers.



3. Fill the bottom section. **Around half full is suggested.** If 100% full, the large would weigh 22kg, and the small would weigh 10kg. Half full would weigh 10kg+ and 5kg+ (easier to carry, less stress on the handles, and still stays upright fine).



4. Close the valve and stopper on this bottom section.



5. Close the 1-way valve on the top section, and you're ready to inflate. If inflating by mouth, it'll take 1 minute for the small, and 3 minutes for the large (suggest taking a short break every minute). Using a pump can work if the valve size matches. **Do not overinflate.** Just inflate until it is solid enough, not *very hard*.



6. Close the stopper, and inflation is finished. You can lift it by the handles to move it. **Turn the handles toward the back before use.**



7. A sticker patch is included in case of needing to repair a puncture/air leak.

- Release air from the defender.
- Cut repair patch to size.
- Thoroughly clean the damaged surface, allow to dry for 10 minutes.
- Remove sticker patch from paper backing.
- Apply patch firmly over the hole.
- Do not inflate for 20 minutes.

